

## Godfrey Hirst Hybrid Floors

## Care & Maintenance



Australian Edition Hybrid Flooring

Congratulations on selecting a quality floor designed with easy care and maintenance in mind. To help enjoy the longevity of your floor for many years to come, follow these simple steps:

#### Cleaning & Care

- Immediately clean up any liquid or water based spills or any other
  potentially staining marks using a dry clean cloth. Though Godfrey
  Hirst hybrid floors have a waterproof surface', don't leave liquid/
  water based spills there just to test it. Though Godfrey Hirst floors
  are resistant to most spots and stains, some materials or colourants
  (such as tar, grease, oil, dyes, waxes, ball point, marker pens, or foods/
  beverages containing strong dyes as mustard, curry, cordial, coffee,
  tea etc.) may under certain conditions migrate into the wear layer
  causing indelible stains.
- Daily, or as required remove any loose dirt or grit which could damage the floor by sweeping with a soft dry broom or vacuum (preferably with an effective dust filter and suction nozzle for hard surfaces and turning off power head, if installed).
- Weekly damp mop the floor using water and a PH neutral cleaner to remove any footprints, dirt and other stains or marks.
- As required stubborn scuffs and stains can easily be removed using
  a damp cloth or sponge with a diluted solution of methylated spirits.
  Ensure the methylated spirits is completely rinsed from the floor.

#### When cleaning the floor:

- Never use abrasive cleaners, nylon scouring pads, steel wool, scouring powder or bleach as they may damage the floor.
- Never use oil, soap, wax or polishes as these finishes may make the floor slippery and can leave a dull finish on the floor.
- · Never use a steam-mop or steam-cleaner.

You should also never flood the floor with water. Excessive water can damage your floor. Promptly soak up bulk liquid spills.

### **Protect Your Floor**

# Follow these simple steps to achieve many years of enjoyment from your Godfrey Hirst hybrid floor:

- Place entrance mats (it is recommended to avoid using mats with a rubber backing) at all exterior doorways and entrances to trap dirt, sand, grit, moisture and other substances from shoes. Double mats (a coarse exterior mat and medium interior mat) are recommended for residential installations and triple commercial mats with a minimum walk off zone of 3.5 metres for commercial installations. Clean mats regularly.
- Use non-staining felt protectors under heavy pieces of furniture.
   Fit office chairs, filing trolleys, mobile containers and furniture, with soft treads or castors. Chair pads should be used under desk chairs with castors.

- Heavy objects and furniture (200kg or greater), such as large bookcases as large bookcases, full sized billiard tables, freestanding bathtubs or kitchen units should not be situated on any floating installation. This can lead to the floor failing to respond to contraction and expansion, which can cause squeaking, gapping and possible failure.
- Never drag, slide or roll furniture or appliances across your floor.
   Protect the surface if using a trolley to move heavy objects.
- Spiked heels or shoes in need of repair can severely damage your floor. In areas of excessive traffic and wear, make use of runners or area rugs. Rugs should be cleaned regularly.
- · Pet claws can scratch your floor. Keep nails trimmed.
- Floor to ceiling windows coupled with the Australian sun can create floor surface temperatures over 70°C. Godfrey Hirst hybrid flooring is manufactured to be stable in low and high temperatures (0-55°C). However, your floor should be protected from extreme temperatures and strong direct sunlight by the use of interior temperature and humidity control (recommended temperatures 10-30°C and relative humidity levels between 30% and 70%), window tinting, awnings and/or curtains/ blinds. Dramatic temperature changes and/or extreme humidity can cause joins to lip/gap and prolonged direct sunlight will cause fading.

#### **Common Characteristics of Hybrid Floors**

- Hybrid flooring products can display discolouration caused by contact
  with rubber products such as rug/mat backings, furniture feet, rubber
  soled shoes/slippers, wheels for trolleys and wheelchairs etc. which
  are likely to leave permanent marks. Only non-staining vinyl backed
  mats or woven rugs identified as colourfast should be used on hybrid
  floors. If the floor is to be subjected to any of these applications, darker
  colours are recommended which will hide any discolouration, should
  it occur.
- · Hybrid floors cannot be sanded.
- Even though Godfrey Hirst hybrid floors are exceptionally stable, planks can still be subject to some shrinkage and growth during changes in climatic conditions leading to small gaps between planks. This is a normal feature of hybrid floors and not considered a manufacturing defect.

**Commercial Installations** - Additional maintenance may be required for commercial installations. Please contact your Godfrey Hirst Account manager or visit www.ghcommercial.com.

^Subject to proper installation, maintenance and local building code / regulatory approval